









# ASSEMBLY INSTRUCTION

# DINING TABLE



Read instructions carefully. Refer hardware and furniture part list for guidance. Be sure all parts are complete, before assembling, place all wooden furniture part on a clean and flat soft surface to prevent scratches. refer steps provided as assembling guide.

**CAUTION :**

1. Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.
2. To prevent thread damage, ensure that nuts or nuts bolts are not over tighten.
3. Hardware are to be kept out reach from children

PART LIST			HARDWARE LIST		
ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY
A	TABLE TOP	1 PC	1	HEX COM SCREW 5/16" X 3" (BLACK) 	8 PCS
B	TABLE LEG	4 PCS	2	SPRING WASHER 5/16" (BLACK) 	8 PCS
			3	FLAT WASHER 5/16" (BLACK) 	8 PCS
			4	SPANNER 12.8 	1 PC
			5	JCBC SCREW M6 X 80MM (RB) 	8 PCS
			6	SPRING WASHER (RB) 	8 PCS
			7	FLAT WASHER M6 X 13MM (RB) 	8 PCS
			8	ALLEN KEY M4 (BALL SHAPE) 	1 PC

**STEP 1**



COMPLETED ASSEMBLY