















ASSEMBLY INSTRUCTIONS

DINING CHAIR MODEL# : UDC9072



| | | | |
|--|--|--|---|
| ①  X 1 | ②  X 1 | ③  X 4 | ④  X 1 |
| A  M8X 35 X 4 | B  X 4 | C  Ø8X 20 X 4 | D  5# X 1 |
| E  M6X 25 X 4 | F  4# X 1 | G  M6X 18 X 4 | H  Ø6X16 X 4 |

